

Elwis PRO 450 UV-R

Article nr. 14058R

Product description

Rechargeable COB handlamp with 300/400/450/160 lumens

Specifications

Housing	Rubber
Lens	PC
On/off switch	1st. 2700K/300 lumens 2nd 4000K/400 lumens 3rd 6400K/450 lumens 4th. torch 160 lumens For UV: (When the light is off) hold down the switch for 3 second: UV ON Hold down the switch for 3 second again: UV OFF (When the light is ON) Hold down the switch for 3 second: light PFF Hold down the switch for 3 second again: UV ON Hold down the switch for 3 second again: UV OFF
Magnet	Back and bottom
Hook	Back
Pocket clip	No
Battery type	18650 type 3.7V 2600mAh.
Light source	COB
Colour temperature (Kelvin)	2700/4000/6400
Colour rendering index (CRI)	>95
Charger operating voltage (charger not supplied in box!)	5V 1A
Output (lumen)	300/400/450/160
Run time (hours)	1.3 / 4 (torch) / 5 (UV) 4 indicators
Charging time (hours)	N/A
Charging level indicator	N/A
Protection class	IK07 / IP65
Operating temperature range (Celcius)	-10-40
Charging port	USB C
Charging port cover	Rubber



Product data

Lamp weight (g)	300
Lamp dimensions (cm)	5.6*3.9*20.3
EAN code box (1 pc)	5703296441544
EAN code inner carton/display EAN code outer carton Harmonized standard code	5703296442541 5703296443548 8513100000

Packaging

Description	"PRO" design printed box
Box size (cm)	7.5*4.5*21
Box weight (g)	45
Carton quantity (pcs)	40 (outer carton)
Carton size (cm)	47.5x35.8x25.5 (outer carton)
Carton weight (kg)	(outer carton)

Features

- Rechargeable
- Battery indicator
- Magnets both on back and bottom 180
- flexible handle

The following Safety Instructions apply
(Where relevant)

General Safety instructions
Do not shine in eyes. Do not immerse in water or other liquids. Do not cover the lens when turned on and do not place the product with the lens/light source direct on a surface. Do not operate if the housing, wiring compartment or lens is open, missing, or damaged. Allow the product to cool down sufficiently before cleaning. Do not use cleaners that contain abrasives or solvents. Use on flat, stable surfaces. Do not operate with wet hands. Do not disassemble. Do not attempt to repair if damaged. Repairs must only be carried out by the manufacturer or authorized service representative. Clean with a dry clean cloth. Please note that lighting products generate heat – if the heat exceeds 60 degrees turn off the product.

Safety Instructions - rechargeable products
Always inspect the charging plug - it must look dry, clean and undamaged. Only use the supplied charging cable and/or charger. Do not use a modified or damaged charger. Do not try to charge the product if it looks damaged. Do not turn on when charging. Do not leave on charge for over 24 hours. Do not charge below 0°C, above 40°C or at high humidity. Do not leave the product on charge near flammable material as it can cause a fire. Never charge without supervision. Always pay extremely attention to Li-ion batteries as they can explode, if not handled properly, the battery may cause explosion, leakage or fire. Do not expose batteries to direct sunlight. Do not disassemble or modify batteries. Do not apply strong impacts to the battery. Do not get batteries wet Keep batteries out of reach of children and animals. Do not place batteries on top of an electromagnetic field. Do not use batteries that work for an extremely short period of time. Do not short-circuit the battery. Do not put a battery in a microwave oven, pressure container, or other such devices. Do not recharge batteries where heat can build up. If not handled properly, the battery may cause explosion, leakage, or fire.

Safety Instructions – alkaline batteries
Only use new and undamaged batteries. Remove batteries from a device that is not being used for an extended period as they can leak. Never try to charge a non-rechargeable battery.